

Comprehensive assembly of the swivel wheels on the Edward rollaway bed

- 1) Run bolt through wheel mount, then through the frame
- 2) Add washer, then add nut.
- 3) Fix bolt head with 1/2 wrench, (13mm) when screwing in the nut (firmly) using a another 1/2 (13mm) socket wrench, or similar.
- 4) Done!

